

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5

		SETTING INFORMATION			
		00	01	10	11
INPUT DATA	00	0	0	0	1
	01	1	0	1	0
	10	1	0	1	0
	11	1	1	0	0

FIG.6




FIG.7

		OUTPUT DATA	
		OUT1	OUT2
SETTING INFORMATION	0000	A	A
	0001	A	B
	0010	A	C
	0011	A	O
	0100	B	A
	0101	B	B
	0110	B	C
	0111	B	O
	1000	C	A
	1001	C	B
	1010	C	C
	1011	C	O
	1100	O	A
	1101	O	B
	1110	O	C
	1111	O	O

FIG.8




FIG.9




FIG.10

		SETTING INFORMATION			
		00	01	10	11
INPUT DATA	00	01	01	01	00
	01	10	01	10	01
	10	10	01	10	10
	11	10	10	01	11

FIG.11




FIG.12





FIG.13

1400 JUMP SETTING INFORMATION



1404 JUMP DESTINATION ADDRESS

1403 JUMP DESTINATION ADDRESS

1402 SELECTION CODE

1401 CODE INDICATING A JUMP

FIG.14




FIG.16




FIG.15




FIG.17




FIG.18




FIG.19




FIG.20

2100 STOPPING SETTING INFORMATION




FIG.21




FIG.23




FIG.24




FIG.25